


1. PC System Requirements

Ensure that your PC has the following before attempting to install the software.

1. Microsoft Windows XP, Microsoft Windows Vista or Microsoft Windows 7.
2. A maximum of 200MB of free disk space is required.
3. For VisualAdrian, VisualFlonet & VisualPiper, Microsoft Office Visio 2003 or higher with the Macro Security set to Medium.

2. Installing the software

1. You must have **Administration** privileges to install the software.
2. Close any applications you have running before installing PEL.
3. The PEL Installation Kit can be accessed on the PEL website, <http://www.pelsoftware.com>.
4. Click on the PEL Installation Kit on the Downloads | Installation page.



The screenshot shows a website navigation bar with links: Home, Products, Support, Downloads, Documentation, Events, Channel Partners, Contact Us. Below the navigation bar is a section titled "PEL Installations". On the left is an image of a software box and a CD. To the right of the image, the text reads: "Download the PEL software for a 30 day evaluation period - absolutely free!". Below this is a yellow button labeled "PEL Installation Kit (75MB)". Further text says: "When prompted, choose to SAVE the file to your computer and run the installation from there." and "If you would prefer an evaluation CD why not [contact us](#) and we will send one to you without delay." At the bottom, it states: "You will need to register in order to activate PEL. Once you have installed the software, just contact us with your unique licence key and we will activate the software for your 30 day evaluation."

5. If running Microsoft Windows XP, select the **RUN** option followed by the **Complete PEL Installation option** which will take you through the self-explanatory installation procedure.

If running Microsoft Windows 7 or Vista:

1. **Download the installation program**
Select the save option and download the file to any directory.
2. **Run the installation program as administrator:**
In Windows Explorer, navigate to the downloaded PEL installation program, e.g. Setup-PEL19.4.exe, right-click on it and select "Run as administrator", and follow the self-explanatory installation procedure.
3. **Grant users "Full control" permissions in the PEL program folder:**
In Windows Explorer, navigate to the folder in which PEL was installed, e.g. C:\Program Files\PEL. Right-click on it, select "Properties" and click on the "Security" tab of the form that appears. To change permissions, press "Edit...". On the new form, in the list of users and groups select the group "Users" and in the box below click in the box in the "Allow" column for "Full control". This also ticks other boxes. Press OK

See overleaf for instructions on obtaining a PEL Licence.

3. Obtaining a PEL Licence


1. Run the PEL Licence Manager program:

- Click the tab **Request Licence**
- Enter your Name
- Enter your Company Name
- Enter your Contact Telephone Number
- Click the **Generate Request** button.

This will generate a licence request code.

2. E-mail, fax or telephone this code to PEL Support Services using the contact information shown at the end of this procedure.

A Licence file (PEL.LIC) will be sent to you normally within 24 hours.



The screenshot shows the 'Request Licence' tab in the PEL Licence Manager. The user has entered 'M G Pass' as the licence holder name, 'ABB' as the business name, and '01925 74 1148' as the contact number. A 'Generate Request' button is highlighted. Below it, a text box displays the generated request code: '200416082032130'. At the bottom, instructions are provided to email the code to PEL.SUPPORT@GB.ABB.COM.

4. Installing the PEL Licence file


1. When you receive your PEL licence, save it to a temporary location on your PC.

2. Click **Start | Programs | PEL | Licence Manager** to launch the PEL Licence Manager.

3. Click the tab **Install/Renew Licence**

4. Click the **Browse** button to locate the **PEL.LIC** file.

5. Click the **Install Licence** button.



The screenshot shows the 'Install/Renew Licence' tab. The 'Install licence via file' radio button is selected. The full path to the licence file is entered: 'R:\eutech\PEL\Licences\ABB PEL team\MGPass\pel.lic'. A 'Browse...' button is visible. Below, an 'Install Licence' button is highlighted. A text box shows the installation progress: 'Installing new licence', 'Licence File installed on: C:\Program Files\PEL\Licence', 'Re-Initialising licence', and 'New licence successfully installed.'

This program is developed, maintained and supported by PEL Support Services, ABB. We run a Hotline telephone, email, fax, and Internet Help service to answer any queries about the PEL products.

Please send to us any suggestions how you consider we could improve PEL and our service. You can contact us by any of the following routes:

E-mail: pel.support@gb.abb.com
 Telephone: +44 (0)1925 74 1126
 Fax: +44 (0)1925 74 1265
 Website: www.pelsoftware.com

Post: PEL Support Services
 ABB Ltd
 Daresbury Park, Daresbury
 Warrington, Cheshire, WA4 4BT