


1. PC System Requirements

Ensure that your PC has the following before attempting to install the software.

1. Microsoft Windows XP or Microsoft Windows Vista.
2. A maximum of 200MB of free disk space is required.
3. For VisualAdrian and VisualFlonet, Microsoft Office Visio 2003 or higher with the Macro Security set to Medium.

2. Installing the software

1. You must have **Administration** privileges to install the software.
2. Close any applications you have running before installing PEL.
3. Click on the PEL Installation Kit on the Downloads | Installation page.



The screenshot shows a web browser window with a navigation menu at the top: Home, Products, Support, Downloads, Documentation, Events, Channel Partners, Contact Us. The main content area is titled "PEL Installations" and features an image of a software box and CD. The text below the image reads: "Download the PEL software for a 30 day evaluation period - absolutely free!" followed by a link for "PEL Installation Kit (75MB)". Further instructions state: "When prompted, choose to SAVE the file to your computer and run the installation from there." and "If you would prefer an evaluation CD why not contact us and we will send one to you without delay." A final note says: "You will need to register in order to activate PEL. Once you have installed the software, just contact us with your unique licence key and we will activate the software for your 30 day evaluation."

4. Select the **RUN** option followed by the **Complete PEL Installation option** which will take you through the self-explanatory installation procedure.

3. Obtaining a PEL Licence


1. Run the PEL Licence Manager program:

- Click the tab **Request Licence**
- Enter your Name
- Enter your Company Name
- Enter your Contact Telephone Number
- Click the **Generate Request** button.

This will generate a licence request code.

2. E-mail, fax or telephone this code to PEL Support Services using the contact information shown at the end of this procedure.


A Licence file (PEL.LIC) will be sent to you normally within 24 hours.



The screenshot shows the "PEL Licence Manager" application window. It has four tabs: "Licence Monitor", "Request Licence" (which is selected), "Install/Renew Licence", and "Licence Locator". The main area contains a form with the following fields: "Please enter the name of the licence holder for this installation:" with the value "M G Pass"; "Please enter the name of the business that will use this installation:" with the value "ABB"; and "Contact Number (optional):" with the value "01925 74 1148". Below these fields is a "Generate Request" button. The bottom section of the window displays the generated "Licence Request For PEL Software" with the following details: "Request from: M G Pass", "For Business: ABB", "Contact no.: 01925 74 1148", and "Request code: 200416082032130". At the bottom right, there is a "Close" button.

4. Installing the PEL Licence file

1. When you receive your PEL licence, save it to a temporary location on your PC.
2. Click **Start | Programs | PEL | Licence Manager** to launch the PEL Licence Manager.
3. Click the tab **Install/Renew Licence**
4. Click the **Browse** button to locate the **PEL.LIC** file.
5. Click the **Install Licence** button.



5. Notes for System Administrators

1. It is unnecessary to reboot if requested to do so.
2. At the end of the software installation, the location of PEL folder is recorded in one of the PEL configuration files. If PEL is subsequently moved or if users have different letters for their mapping to the network drive (see below) then some PEL applications will not function.
3. Ensure that the PEL folder and sub-folders are set to **Read** and **Execute** for all users of the software except for the Licence folder, which should be set to **Read**, **Write** and **Execute** for both the folder and files it contains.
4. If you have installed the software from a local PC and you intend to uninstall PEL from that PC, be certain to disconnect the network drive before you uninstall PEL. Failure to do so will result in PEL being uninstalled from the **server** as well as the local PC.
5. Ensure that DCOM (Distributed COM) is enabled on each PC that is running on PEL.
6. On **Microsoft Windows Vista** with User Account Control enabled (the default) it may be necessary to ensure that the Licence Manager is "Run as administrator" (even if logged in with administrator privileges) so that registry and file updates are not implemented in a user-specific "virtual" location.

6. Client installation of PEL

1. You must have **Administration** privileges to install the Client software.
2. Each client requires a network drive mapped with an identical letter to the shared server location where the PEL software has been installed, e.g. **P:** set to **\\GBBRHA01\Software**.
3. Close any applications that are running before installing PEL.
5. Go to the Downloads – Product Updates and to the 'Network Installations Only' section. Follow the steps to download the ClientSetup.
6. On installation enter a meaningful **User Name** when prompted. This will enable the user to be identified easily in the PEL Monitor file (see below).


7. When requested for the destination of the software, click the **Browse** button and select the TARGET area where the software was installed, (e.g. P:\PEL) Do not select any of the subfolders under the PEL folder.
8. Reboot the Client PC if requested to do so.

7. PEL Licence Manager Monitor Options

1. Run the PEL Licence Manager and select the tab **Licence Monitor**.

The current users of the programs are listed under Licence Status.

2. To remove any users who have crashed from a program, click the **Tidy Token Monitor File** button.
3. To use the Licence Administration options, you will need to enter a LicenceID, which is **PEL001**.



This program is developed, maintained and supported by PEL Support Services, ABB. We run a Hotline telephone, email, fax, and Internet Help service to answer any queries about the PEL products.

Please send to us any suggestions how you consider we could improve PEL and our service. You can contact us by any of the following routes:

E-mail: pel.support@gb.abb.com
Telephone: +44 (0)1925 74 1126
Fax: +44 (0)1925 74 1265
Website: www.pelsoftware.com

Post: PEL Support Services
ABB Ltd
Daresbury Park, Daresbury
Warrington, Cheshire, WA4 4BT